

New Product

Ultrasonic Tape Measure

Model TM-56

T+M



TM56 Pocket Ultrasonic Tape Measure



- Instant and accurate distance measurement by ultrasonic waves, easily measures the height of a ceiling
- Maximum measuring distance 18m (60ft)
- Displays in m/cm or feet/inch switchable
- For indoor or outdoor use

Technical specifications

Distance range: 0.4~18m

Frequency: 40kHz, Resolution: 0.01m (1/4 in)

Basic accuracy: $\pm 0.5\% + 1 \text{dgt}$ (in still air)

Working temperature: $0^{\circ}\text{C} \sim 50^{\circ}\text{C}$

The maximum distance & accuracy vary depending on environmental conditions such as temperature, humidity, altitude /barometric pressure & wind speed, etc.

Battery: 12Vx1, 23A, Weight: 70g

Test and Measurement Instruments C.C. Tel: +27 (011) 683 4365 Fax: +27 (011) 683 4461

t.m.i@iafrica.com



www.instrumentsgroup.co.za

