

ECT-6030 Battery powered four point indent crimping tool

Features:

1. Three movable indenting nibs push connectors against the top fixed nib. As a result, four indentations are made into the connector.
2. Built in safety valve, automatic pressure-relief at Max. pressure.
3. Crimping head can rotate at any time for any angle.
4. Sudden suspend function can be controlled at any time, manually retract is available.
5. LED light makes it suitable for working in dark environment
6. Temperature sensor inside, under long time working, the fault signal sounds, it indicates the tool can't continue to work until the temperature reduced to the normal.



Model	ECT-6030
Crimping force	6t
Rated pressure	700bar
Crimping capacity	Cu16-300mm ²
Net weight	6kg
Crimping cycle	6-12s(Depend on the size of cable)
Crimp/charge	100times for Cu150mm ²
Charging time	1 hour
Package	Plastic case
Standard accessories	2 batteries 1 charger



TEST AND MEASUREMENT INSTRUMENTS C.C.
www.instrumentsgroup.co.za
Email: sales@instrumentsgroup.co.za
Tel: 011 683 4365