



FLIR VS70 Videoscope

The FLIR VS70 is a rugged, waterproof and shock-resistant videoscope that features intuitive handset controls that enable users to maneuver the narrow camera probe into tight spaces to deliver vivid and sharp video and images to a large 5.7" color LCD display. Advanced inspection solutions, expansion cameras, and add-on accessories enable users to expand their FLIR VS70 to address many different inspection needs.

- Rubber-reinforced case is waterproof and capable of withstanding two-meter drops (IP67-rated)
- Handset controls allow users to select 180-degree or 90-degree camera angles
- Record video and images that transfer to a PC via SD card or USB port
- Voice annotate video recordings to add critical details with included headset
- Extended battery life accommodates a full day of inspections without recharging
- USB-based charging system enables users to charge at home, on the road, or at the job site.
- Base system is also available with a wide range of handsets, camera probes, and wireless options

Includes:

- Hard Case, User Manual, Power Adapter, Headset, Car Charger, Shoulder Strap, Camera Cleaning Kit



TECHNICAL SUMMARY

Display Resolution	640 x 480px
Display Size	5.7in (135mm)
Battery Life	6 to 8hrs (integrated)
Frame Rate	30fps (NTSC & PAL)
Video / Image Transfer	SD Card or USB
Camera Diameter Range*	3.9mm to 28mm
Camera Focal Length Options*	Long View or Short View Macro
Camera Length Range*	0.3m to 30m
Certifications	FCC
Warranty	2 Year

* See www.flir.com/test for comprehensive list of inspection camera options

Ordering Information

VS70-1.....General Purpose Long Focus Wired Solution
 VS70-1W.....Wireless General Purpose Long Focus Solution
 VS70-2.....Small Opening Short Focus Wired Solution
 VS70-3.....Wired Articulation Long Focus Solution
 VS70-3W.....Wireless Articulation Long Focus Solution
 VS70-KIT.....2-Way Articulation and General Purpose Camera
 VS70-KIT-W.....Wireless Articulation and General Purpose Camera



Test and Measurement Instruments C.C.

Tel: 011 683 4365

Fax: 011 583 4461

Email: t.m.i@iafrica.com

Website: www.instrumentsgroup.co.za