



# 1550B MegOhmMeter



Fluke 1550B

## Digital insulation testing up to 5000 Volts

The Fluke 1550B is a digital insulation tester capable of testing switchgear, motors, generators and cables at up to 5000 V DC. It can be used for a wide range of tests: from simple spot checks to timed tests and breakdown tests. Measurement storage and PC interface software make it ideal for preventive maintenance.

- Test voltages of 250 V, 500 V, 1000 V, 2500 V, 5000 V
- Capable of testing in 50 V increments between 250 V and 1000 V and 100 V increments between 1000 V and 5000 V
- Measures 0 to 1 Tera-Ohm
- Warning voltage function alerts the user that line voltage is present and gives the voltage reading up to 600V AC or DC

- Guard system eliminates the effect of surface leakage current on high-resistance measurements
- Large digital/analog LCD shows detailed measurement data
- Cable or insulation capacitance
- Leakage current
- Ramp function (0-5000 V DC) for breakdown testing
- Timer 1 to 99 minutes
- Polarization index and dielectric absorption calculated automatically
- 99 memory locations store all measurements parameters
- Includes Quicklink 1550B Software and Optical Interface cable

## Specifications

Test Voltage (DC)	Range	Accuracy (+/- reading)
250V	200kΩ to 5GΩ 5GΩ to 50GΩ	5% 20%
500V	200kΩ to 10GΩ 10GΩ to 100GΩ	5% 20%
1000V	200kΩ to 20GΩ 20GΩ to 200GΩ	5% 20%
2500V	200kΩ to 50GΩ 50GΩ to 500GΩ	5% 20%
5000V	200kΩ to 100GΩ 100GΩ to 1TΩ	5% 20%
Short circuit current	greater than 1 mA and less than 2mA	
Bar graph range	0 to 1TΩ	
Insulation test voltage accuracy	0% to + 10% at 1mA load current	
Induced AC mains current rejection	2 mA maximum	
Charging rate for capacitive load	5 seconds per μF	
Leakage current	1nA to 2mA	± (5% + 2nA)
Capacitance measurements	0.01μF to 15.00μF	± (15% rdg + 0.03μF)
Live circuit indicator	30V to 600V AC/DC, 50/60Hz	± (5% + 2V)
Timer increments; indicated to within 1 second	1 to 99 minutes; settable in 1 minute	
Ramp	0% to 100% of selected test voltage, or until breakdown.	



LISTED



### Included Accessories

Test leads, 5000 V-rated probes, Alligator clips, Interface cable  
Flukeview Forms Basic, soft carrying case with water-proof bottom, instruction manual

### Ordering Information

Fluke 1550B MegOhmMeter

**Operating Temperature:** -20°C to 50°C

**Storage Temperature:** -20°C to 65°C

**Relative humidity:** 80% at 31°C,

50% at 50°C

**Dust/water resistance:** IP40

**Operating Altitude:** 0 to 2,000 mtrs.

**Batteries:** 12 volt, lead-acid, rechargeable

**Size (HxWxD):** 170 mm x 242 mm x 330 mm

**Weight:** 4 kg (with battery)

**Two Year Warranty**

## Recommended Accessories



FVF-SC2



Supplied By: Tel: (011) 683 4365

[www.instrumentsgroup.co.za](http://www.instrumentsgroup.co.za)

**Test and Measurement Instruments C.C.**