



Link Stick 12m 40ft w/ Bag Hastings

TMHV240



A unique triangular design by Hasting Fiberglass, the originators of Telescoping Hot Sticks. All models are heavy duty designed.

Features and Benefits

Triangular shape enables each section to lock in automatically - no more twisting and turning to lock sections

High visibility - fluorescent tip section is highly visible and has a foam core. All tip sections are 1.15" in diameter. All sections are 100% tested per OSHA and ASTM F-711.

Extra reach - 40' model now available.

Re-designed lock buttons - new shape and larger size are easier to operate with and without gloves.

More versatile - use only the number of required sections to perform each job, Example: a 40 ft. tool can be reduced to a 20 ft. working height by depressing the lock button and sliding the bottom sections off. This allows for a lightweight tool to perform the work easier.

Easy disassembly - simply depress the lock button and slide section, out . No tools are required for disassembly.

Ergonomic design - gives the operator a "better gripping" surface for better control.

Reduces inventory - only one size lock button and spring for replacement needs.

Easy maintenance - all sections have a smooth glossy surface for routine cleaning and waxing.

New base cap - Cushions and protects base end.

Improved universal head - strong aluminum alloy head incorporates corona discharge design and "includes a captive belleville washer" to hold universal attachments securely.



Supplied by:

TEST AND MEASUREMENT INSTRUMENTS C.C.

Tel: 011 683 4365

www.instrumentsgroup.co.za Email: sales@instrumentsgroup.co.za