

ECT-12042 Battery powered hydraulic crimping tool

Features:

1. C-head with 42mm opening width, easy connector pick & place, suitable for crimping sleeves
2. Built in safety valve, automatic pressure-relief at Max. pressure
3. Built-in micro chip controller, more crimping times with one time charger, protect the device body.
4. Crimping head rotates 360°, suitable for different angle
5. Sudden suspend function can be controlled at any time, manually retract is available.
6. LED light makes it suitable for working in dark environment
7. Temperature sensor inside, under long time working, the fault signal sounds, it indicates the tool can't continue to work until the temperature reduced to the normal.



Model	ECT-12042
Crimping force	12t
Rated pressure	700bar
Crimping capacity	Cu16-400mm ²
Net weight	6kg
Crimping cycle	6-18s(Depend on the size of cable)
Crimp/charge	100times for Cu150mm ²
Charging time	1 hour
Package	Plastic case
Standard accessories	Crimping dies from 50-400mm ² , 2 batteries 1 charger



TEST AND MEASUREMENT INSTRUMENTS C.C.
www.instrumentsgroup.co.za
Email: sales@instrumentsgroup.co.za
Tel: 011 683 4365